

R. SEIDLEIN
1/2


Start
RECEIVE ACCESS REQUEST THAT INCLUDES ACCESS TERMINAL ID
201
IS LOCATION OF ACCESS TERMINAL IN DATABASE ?
202
NO
SEND LOCATION QUERY TO ACCESS TERMINAL
203
RECEIVE CURRENT LOCATION OF ACCESS TERMINAL
204
RETRIEVE LOCATION OF ACCESS TERMINAL FROM DATABASE
205
SEND LOCATION QUERY TO AUTHORIZED USER'S MOBILE TERMINAL
206
RECEIVE LOCATION FROM MOBILE TERMINAL
207
COMPARE LOCATIONS OF ACCESS TERMINAL AND AUTHORIZED USER'S MOBILE TERMINAL
208
THE SAME ?
209
210
GRANT ACCESS
DENY ACCESS
211
END